

Model: nanoKEY2

**MIDI Implementation Chart**

Function...		Transmitted	Recognized	Remarks
Basic Channel	Default Changed	1 – 16 1 – 16	1 – 16 1 – 16	Memorized
Mode	Default Messages Altered	× ○ *****	× ×	*1
Note Number:	True Voice	0 – 127 *****	× ×	
Velocity	Note On Note Off	○ 9n, v=1 – 127 × 8n, v=64	× ×	
After touch	Key's Channel	× ×	× ×	
Pitch Bend		○	×	PITCH button
Control Change	0 – 127	○	×	MOD button, SUSTAIN button *1
Program Change	Variable Range	× *****	× *****	
System Exclusive		○	○	*2
System Common	Song Position Song Select Tune Request	× × ×	× × ×	
System Real Time	Clock Commands	× ×	× ×	
Aux Messages	Local On/Off All Notes Off Active Sense System Reset	○ ○ × ×	× × × ×	*1 *1
Notes	*1: Valid if assigned as a MIDI control change. *2: In addition to Korg exclusive messages, also responds to inquiry messages.			

Mode 1: OMNI ON, POLY

Mode 2: OMNI ON, MONO

O: Yes

Mode 3: OMNI OFF, POLY

Mode 4: OMNI OFF, MONO

X: No

Consult your local Korg distributor for more information on MIDI implementation.